# 5137R RESCO MULTICOM WALL PANELLING SYSTEM

# 1. GENERAL

This section relates to the supply and installation of  $\mbox{RESCO}$  Multicom $\mbox{\ensuremath{\mathbb{B}}}$  pre-finished proprietary wall panelling system for:

- wet and damp locations
- high impact areas
- high hygiene areas

# 1.1 ABBREVIATIONS AND DEFINITIONS

Refer to the general section 1232 INTERPRETATION & DEFINITIONS for abbreviations and definitions used throughout the specification.

# Documents

1.2 DOCUMENTS REFERRED TO

Refer to the general section 1233 REFERENCED DOCUMENTS. The following documents are specifically referred to in this section: <u>NZBC C</u>/AS2-AS7 Protection from fire IS EN 438-4 High-pressure decorative laminates (hpl) - sheets based on thermosetting resins (usually called laminates) - part 4: Classification and specifications for compact laminates of thickness 2mm and

# JIS Z 2801 Antibacterial products - Test for antibacterial activity and efficacy

Documents listed above and cited in the clauses that follow are part of this specification. However, this specification takes precedence in the event of it being at variance with the cited document.

# 1.3 MANUFACTURER/SUPPLIER DOCUMENTS

Manufacturer's and supplier's documents related to this section are: Resco Multicom: Product Information Guide & Installation Instructions Resco Antibac Fact Sheet Resco Colour Sample Folder Fire Test Report FH5110, Group Classification 3 Greenguard Compliance Certificate BRANZ Appraisal 869 - Multicom® Wall Panel System

Copies of the above literature are available from **RESCO** Ltd. Web: <u>www.resco.co.nz</u> Email: service@resco.co.nz Telephone: 0800 800 950 Auckland: 09 415 5720 Hamilton: 07 850 1025 Facsimile: 07 850 1026

# **Requirements**

#### 1.4 NO SUBSTITUTIONS Substitutions are not permitted to any specified **RESCO** brand products, components or accessories.

# 1.5 SAMPLES

Submit on request samples of panels and components for approval of colour and finishes.

# 1.6 QUALIFICATIONS

Installers to be experienced, competent and familiar with the materials and techniques specified. Install to **RESCO** Installation Instructions current at the time of installation.

#### Warranties

1.7 WARRANTY - MATERIALS Provide the **RESCO** warranty.

10 years: For the compact laminate panel's integrity and aluminium jointers

- Provide this warranty on the **RESCO** standard form.
- Commence the warranties from the date of completion.

Refer to the general section 1237 WARRANTIES - MATERIALS for additional requirements.

# 2. **PRODUCTS**

#### **Materials**

2.1 WALL PANELS

6mm compact laminate panels with black core made from thermo-setting resins to IS EN 438-4. Certified antimicrobial to JIS Z 2801 to prevent the growth of bacteria on the surface up to 99% within 24 hours. Refer to SELECTIONS for colour options.

# Components

- 2.2 JOINTERS AND CORNER PROFILES Selected extruded aluminium 6060 alloy full length aluminium powder coated jointers and corner profiles to suit application. Refer to SELECTIONS for channel colour options.
- 2.3 DOUBLE-SIDED TAPE 2mm Multicom® double sided tape.
- 2.4 ADHESIVE Soudaseal adhesive.
- 2.5 CLEANER Activator cleaning solution, used to wipe down panel and batten and other components that the adhesive is to bond with.
- 2.6 PROFILE FIXING Use fit for purpose stainless steel screws.
- 2.7 BATTENS & VENTILATION STRIP 18mm x 40mm H3.1 battens and PVC ventilation strip to allow heat and moisture to equalize behind the panels.

# 3. EXECUTION

# Conditions

- 3.1 HANDLE AND STORE Store inside and keep in original packaging until needed. Do not store in sun or rain or at high temperatures. Do not walk over the panels. Use caution, machined edges may be razor sharp. Do not slide panels; lift them carefully to prevent scratching. Ensure free of dust and debris. Large panels are a two man lift.
- 3.2 SUBSTRATES CHECK Before commencing installation of the **RESCO** Multicom® system, ensure all substrates are plumb, level and in true alignment, all flooring surfaces are ready and all plumbing

fittings are properly positioned. Ensure adequate provisions are made for fixing to relevant walls.

3.3 PROTECT

Protect adjoining areas, surfaces and finish from damage.

# Application

- 3.4 INSTALL BATTENS & VENTILATION STRIP Use non-corrosive fixings to fix 18mm x 40mm H3.1 battens at 600mm centres and ventilation strip on the bottom end. Battens and vent strip may be excluded in dry areas.
- 3.5 INSTALL ALUMINIUM JOINTERS AND CORNER PROFILES Install aluminium jointers and corner profiles as required to the requirements of **RESCO** Ltd and **RESCO** Installation Instructions.
- 3.6 ACTIVATOR SOLUTION Wipe all surfaces with activator solution that will be in contact with Soudaseal adhesive.
- 3.7 DOUBLE-SIDED TAPE Fix continuous full height double-sided tape to wall areas, to hold panels while Soudaseal adhesive cures.

# 3.8 SOUDASEAL Apply a continuous full height 5mm bead of Soudaseal adhesive to areas where wall panelling to be fixed.

# 3.9 INSTALL PANELS

Dry fit every **RESCO** Multicom® sheet before applying double-sided tape and Soudaseal adhesive. Allow for a 3mm expansion clearance between profiles and panel edges. Carry out the fixing, erection and fitting to finish rigid, plumb, true to line and best practice, to the requirements of **RESCO** Ltd and **RESCO** Installation Instructions. The panels can be cut with a skill saw using fine-tooth tungsten tipped blade.

# Completion

- 3.10 REPLACE Replace damaged or marked elements.
- 3.11 LEAVE Leave work to the standard required by **RESCO** Ltd.
- 3.12 REMOVE Remove debris, unused materials and elements from the site.
- 4. SELECTIONS

# 4.1 SURFACE FIRE PROPERTIES

Group Number	Panel/Finish	Location
3	Compact Laminate	~

# 4.2 RESCO MULTICOM® WALL PANELS

RESCO
Multicom®
6mm pre-finished compact laminate wall-panel
2450mm x 1850mm x 6mm
Resco Antibac range, ~
Interpon powder coated range, ~